



RUST BUSTER

RB7143
Rear Body/Bed Mount
1988-1995 Toyota Hilux / Pickup Trucks



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Wrench
Fire Extinguisher
Hammer

KIT CONTAINS

Rear Body/Bed Mount

QTY

1



RUST BUSTER

RB7143

Rear Body/Bed Mount

1988-1995 Toyota Hilux / Pickup Trucks

1) **PREPARING YOUR VEHICLE**

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) **PREPARING YOUR WORKSTATION**

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

RB7143 Rear Body/Bed Mount 1988-1995 Toyota Hilux / Pickup Trucks

3) **PREPARING FOR YOUR INSTALL**

Remove the bolt from your truck bed and bed mount. Then, lift or remove the bed from your truck.

4) **CUT**


Cut off the factory rear body/bed mount and any obstructions in the work area.



Grind the frame free of rust and debris, revealing bare metal.



Spray the work area with a weld-through primer to help prevent against rust development.



5) **WELD**

Take your replacement rear body/bed mount and hold it up to the silhouette where the factory mount was originally located.





RUST BUSTER

RB7143 Rear Body/Bed Mount 1988-1995 Toyota Hilux / Pickup Trucks

Following proper welding procedures, tack weld your mount onto the frame before welding it on fully. Weld 100% around all edges.



6) **PAINT**

Paint the part with primer or other rust inhibitor to help prevent or reduce the risk of rust formation.

We recommend our Rust Buster Rust Converter & Primer Spray Paint (RB9917)



7) **REINSTALL**

Reinstall your bed.