




RUST BUSTER

RB7397L & RB7397R
Core Support Mount
2014-2018 Chevy/GMC Silverado/1500



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Core Support Mount

QTY

1



RUST BUSTER

RB7397L & RB7397R Core Support Mount 2014-2018 Chevy/GMC Silverado/1500

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

RB7397L & RB7397R Core Support Mount 2014-2018 Chevy/GMC Silverado/1500

3) PREPARING FOR YOUR INSTALL

Remove the body bolts and bushings from the side of the vehicle you are working on, and lift the body up off the frame rail to provide you with more cutting and welding clearance. Remove or relocate any lines and power harnesses from the work area.




4) CUT

Begin cutting away the mount.



Grind the work area free of rust and debris, revealing bare metal.



Coat the work area with a weld through primer to help prevent against further rust development.



5) WELD

Hold the new mount up to the frame while using the outline of the factory mount to help with alignment.





RUST BUSTER

RB7397L & RB7397R Core Support Mount 2014-2018 Chevy/GMC Silverado/1500

Tac weld the part, and verify the part's alignment.



Finally, reinstall your body mount bolts and bushings.



Remove any potential fire hazards from the work area. Following proper welding procedures, weld 100% around all edges of frame section.



6) **PAINT AND PROTECT**

Coat the part and work area with a primer or other rust inhibitor to help prevent or reduce the risk of rust formation. **We recommend our Rust Buster Rust Converter and Primer Spray Paint (RB9917).**

