



# RUST BUSTER

**RB7830L & RB7830R**  
**2011-2019 Chevy/GMC**  
**Silverado & Sierra 2500HD/3500HD**  
**Front Bed Mount**



#### **REQUIRED TOOLS**

Jack Stands or Lift  
Mig Welder  
Paint/Primer  
Hand Grinder  
Cutting Wheel or Torch  
Welding Gloves  
Welding Hood/Shield  
Ear & Eye Protection  
Sockets & Ratchet  
Fire Extinguisher  
C-Clamps

#### **KIT CONTAINS**

Front Bed Mount

#### **QTY**

1



# RUST BUSTER

## RB7830L & RB7830R 2011-2019 Chevy/GMC Silverado & Sierra 2500HD/3500HD Front Bed Mount

### 1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

**Keep all flammable materials away from the vehicle work area.**

### 2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



### WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



# RUST BUSTER

## RB7830L & RB7830R 2011-2019 Chevy/GMC Silverado & Sierra 2500HD/3500HD Front Bed Mount

### 3) CUT & CLEAN

Remove the factory bed mount bolt and bushing. Remove the factory front bed mount using a torch or other cutting tool.



Grind away any debris left by the factory mount, revealing bare metal on the frame rail.



### 4) PREPARING FOR YOUR INSTALL

Spray the work area with a weld-through primer to protect your frame from future rust development.



### 5) WELD

Using the silhouette of the factory bed mount, align the new mount on the frame. You may temporarily re-install your body mount bolt and bushing to ensure proper alignment. Following proper welding procedures, tack weld the part to the frame before welding completely. Weld 100% around all edges.



### 6) PAINT AND PROTECT

Coat the part and work area with a primer or other rust inhibitor to help prevent or reduce the risk of rust formation.



We recommend our Rust Buster Rust Converter and Primer Spray Paint – RB9917.