



**RUST
BUSTER**
F R A M E W O R K S

RB8628L & RB8628R

**2000-2006 Toyota Tundra
Rear Body Mount**



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Locking Pliers
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Rear Body Mount
M10 Flanged Hex Bolt

QTY

1
2



RUST BUSTER

F R A M E W O R K S

RB8628L & RB8628R

2000-2006 Toyota Tundra Rear Body Mount

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

F R A M E W O R K S

RB8628L & RB8628R

2000-2006 Toyota Tundra
Rear Body Mount

3) PREPARE YOUR VEHICLE

Remove the rear body mount bolt and bushing.



4) CUT

Begin cutting away the body mount, followed by cleaning the frame of rust and debris, revealing bare metal.



Coat the work area in a weldable primer to help prevent against further rust development.



5) WELD

Begin welding the part to the frame around all edges.



Finally coat the part with a primer to help prevent against further rust development.

